

## 1 Before driving

### 1-1. Key information

Keys ..... 20

### 1-2. Opening, closing and locking the doors and trunk

Smart access system with push-button start ..... 24

Wireless remote control ..... 36

Doors ..... 39

Trunk ..... 43

### 1-3. Adjustable components (seats, mirrors, steering wheel)

Front seats ..... 46

Driving position memory (driver's seat) ..... 48

Seat position memory (front passenger's seat) ..... 52

Head restraints ..... 54

Seat belts ..... 56

Steering wheel (manually adjustable type) ..... 62

Steering wheel (power-adjustable type) ..... 63

Anti-glare inside rear view mirror ..... 65

Outside rear view mirrors ..... 66

### 1-4. Opening and closing the windows and moon roof

Power windows ..... 69

Moon roof ..... 71

### 1-5. Refueling

Opening the fuel tank cap ..... 74

### 1-6. Theft deterrent system

Engine immobilizer system ..... 77

Alarm ..... 79

Theft prevention labels (U.S.A.) ..... 81

### 1-7. Safety information

Correct driving posture ..... 82

SRS airbags ..... 84

Front passenger occupant classification system ..... 95

Child restraint systems ..... 100

Installing child restraints ..... 104

## 2 When driving

### 2-1. Driving procedures

Driving the vehicle ..... 116

Engine (ignition) switch ..... 126

Automatic transmission ..... 131

Manual transmission .....	137
Turn signal lever .....	139
Parking brake .....	140
Horn.....	141

## 2-2. Instrument cluster

Gauges and meters .....	142
Indicators and warning lights.....	148
Multi-information display .....	151

## 2-3. Operating the lights and windshield wipers

Headlight switch.....	156
Fog light switch .....	159
Windshield wipers and washer.....	160
Headlight cleaner switch .....	165

## 2-4. Using other driving systems

Cruise control .....	166
Dynamic radar cruise control.....	170
Intuitive parking assist .....	180
Driving assist systems.....	186
PCS (Pre-Collision System) .....	192

## 2-5. Driving information

Cargo and luggage.....	196
Vehicle load limits.....	199
Winter driving tips .....	200
Trailer towing.....	204
Dinghy towing (vehicles with an automatic transmission).....	205
Dinghy towing (vehicles with a manual transmission) .....	206

## 3 Interior features

### 3-1. Using the air conditioning system and defogger

Automatic air conditioning system .....	210
Rear window and outside rear view mirror defoggers .....	218

### 3-2. Using the audio system

Audio system type .....	219
Using the radio .....	222
Using the CD player .....	229
Playing back MP3 and WMA discs.....	235
Optimal use of the audio system .....	241
Using the AUX adapter .....	244
Using the steering wheel audio switches.....	245

**3-3. Using the interior lights**

Interior lights list.....	247
• Interior lights .....	249
• Personal lights .....	249

**3-4. Using the storage features**

List of storage features.....	251
• Glove box.....	251
• Console boxes .....	252
• Overhead console.....	253
• Cup holders.....	254
• Bottle holders/door pockets .....	256

**3-5. Other interior features**

Sun visors.....	257
Vanity mirror.....	258
Clock.....	259
Satellite switches .....	260
Ashtrays .....	263
Cigarette lighter .....	264
Power outlet.....	265
Seat heaters.....	266
Seat heaters and ventilators.....	269
Armrest .....	272
Rear sunshade.....	273
Trunk storage extension.....	275
Coat hooks .....	276
Floor mat.....	277
Trunk features.....	278
Garage door opener.....	281
Compass.....	287

**4 Maintenance and care****4-1. Maintenance and care**

Cleaning and protecting the vehicle exterior .....	292
Cleaning and protecting the vehicle interior.....	295

**4-2. Maintenance**

Maintenance requirements ....	298
General maintenance.....	300
Emission inspection and maintenance (I/M) programs .....	303

**4-3. Do-it-yourself maintenance**

Do-it-yourself service precautions .....	304
Hood.....	307
Positioning a floor jack.....	308
Engine compartment.....	310
Tires .....	325
Tire inflation pressure.....	336
Wheels.....	340
Air conditioning filter.....	342
Electronic key battery .....	345
Checking and replacing fuses .....	347
Headlight aim.....	361
Light bulbs .....	363

## 5 When trouble arises

### 5-1. Essential information

Emergency flashers.....	372
If your vehicle needs to be towed .....	373
If you think something is wrong .....	379
Fuel pump shut off system .....	380
Event data recorder .....	381

### 5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds... ..	383
If a warning message is displayed .....	392
If you have a flat tire.....	404
If the engine will not start .....	413
If the shift lever cannot be shifted from P .....	415
If you lose your keys .....	416
If the electronic key does not operate properly .....	417
If the vehicle battery is discharged .....	421
If your vehicle overheats .....	424
If the vehicle becomes stuck.....	427

## 6 Vehicle specifications

### 6-1. Specifications

Maintenance data (fuel, oil level, etc.).....	430
Fuel information.....	446
Tire information .....	449

### 6-2. Customization

Customizable features .....	461
-----------------------------	-----

### 6-3. Initialization

Items to initialize .....	467
---------------------------	-----

## 7 For owners

Reporting safety defects for U.S. owners.....	470
Seat belt instructions for Canadian owners (in French).....	471

## Index

Abbreviation list .....	474
Alphabetical index.....	476
What to do if... ..	486